


How to connect the miniDV and DVD/VHS decks to the MACs

You will need the 4-pin to 6-pin Firewire (1394) cable from the desk.



1. Disconnect the 4-pin Firewire cable from the MiniDV deck.





2. Connect the 4-pin (small) end of the Firewire cable from the desk into the miniDV deck. you got



3. Connect the 6-pin (big) end of the FireWire into the Firewire port at the front of the Mac G5 (or the back of the Mac Mini).



4. You should be able to connect to the "external device" on either iMovie or Final Cut Pro on the Macs.

How to connect the DVD/VHS Deck to the MACs

You will need the 6-pin to 6-pin Firewire cable from the desk.



1. Disconnect the 6-pin Firewire cable from the front of the DV/AV Converter.



2. Connect one end of the Firewire cable you got from the desk into the Firewire port in the front of the DV/AV Converter.
3. Connect the other end of the Firewire cable you got from the desk into the Firewire port at the front of the Mac G5 (or the back of the Mac Mini).
4. You will need to follow the directions for capturing video from the DVD/VHS deck.